



BROWNING SPHERE CFT 3500

Key No. Description

1	DRAG KNOB ASSEMBLY
2	RETAINING RING
3	KEY WASHER
6	DRAG WASHER
7	WASHER
8	WASHER
9	CLICKER
10	CLICK HOLDER
11	KEYED WASHER
12	SCREW
13	RETAINER
14	ROTOR NUT
15	PIVOT ARM
16	ROTOR COVER SCREW
17	BAIL HOLDER
18	KICK LEVER
19	COIL SPRING
20	ROTOR
21	BALL BEARING
22	LINE ROLLER
23	SPACE WASHER
24	LINE ROLLER COLLAR
25	BAIL ARM
26	SCREW
27	BAIL CAM SCREW
28	BALL BEARING
29	E-CLIP
30	E-CLIP
31	BAIL ASSEMBLY
32	BALL BEARING
33	Pin
34	SCREW
35	WASHER
36	BODY COVER-A
37	BODY COVER-B

Key No. Description

38	SPOOL SHAFT
39	SCREW
40	SCREW
41	CLUTCH RETAINER
42	ONE WAY CLUTH
43	CLUTCH HOLDER
44	BALL BEARING
45	TRIP LEVER
46	PINION
47	HANDLE SCREW CAP
48	BODY COSMETIC RING_R
49	BEARING COVER
50	CLICK TONGUE SPRING
51	A/R CAM
52	A/R SWITCH
53	BAIL SPRING
54	BODY
55	REAR CAP
56	SCREW
57	BALL BEARING
58	MAIN GEAR
59	BALL BEARING
60	SCREW
61	BODY COVER
62	BODY COSMETIC RING_L
63	BALL BEARING
64	O/S GEAR
65	SCREW
66	CROSSWIND BLOCK
67	SCREW
68	CROSSWIND BLOCK PLATE
69	SCREW
70	HANDLE ASSEMBLY
71	SPOOL ASSEMBLY