



TROPHY RD 320/330/340

- | | | | | | |
|----|---------------------|----|--------------------|----|---------------------|
| 1 | SPOOL ASSY. | 23 | SPRING | 45 | BODY COVER BUSHING |
| 2 | MAIN SHAFT | 24 | BAIL ARM COVER | 46 | MAIN BODY COVER |
| 3 | HEXAGON NUT | 25 | SCREW | 47 | SCREW |
| 4 | SCREW | 26 | SCREW | 48 | SCREW |
| 5 | ROTOR SHELL | 27 | LOCATING COVER | 49 | HANDLE ASSY. |
| 6 | BAIL HOLDER COVER | 28 | BALL BEARING | 50 | O/S GEAR |
| 7 | SCREW | 29 | LOCATING DEVICE | 51 | O/S GEAR CLIP |
| 8 | BALANCE | 30 | SPRING | 52 | SCREW |
| 9 | SCREW | 31 | ONE WAY | 53 | O/S SLIDER |
| 10 | BAIL ARM | 32 | BALL BEARING | 54 | O/S SLIDER FASTENER |
| 11 | SCREW | 33 | PINION GEAR | 55 | REAR COVER |
| 12 | LINE ROLLER WASHER | 34 | ANTI-REVERSE SHAFT | 56 | CLICK GEAR WASHER |
| 13 | LINE ROLLER BUSHING | 35 | ANT-REVERSE KNOB | 57 | CLICK GEAR |
| 14 | LINE ROLLER | 36 | SPRING LEVER | 58 | BRAKE WASHER |
| 15 | BAIL SPING NUT | 37 | SCREW | 59 | EARED WASHER |
| 16 | BAIL SPRING | 38 | MAIN BODY | 60 | KEY WASHER |
| 17 | BAIL HOLDER | 39 | SCREW | 61 | BRAKE SPRING |
| 18 | SCREW | 40 | PAPER WASHER | 62 | BRAKE SCREW |
| 19 | SCREW | 41 | HANDLE CAP/SCREW | 63 | DRAG KNOB |
| 20 | BAIL ARM SLIDER | 42 | BODY BUSHING | 64 | CIRCLIP |
| 21 | BALANCE | 43 | DRIVE GEAR | 65 | RUBBER CASING |
| 22 | SPRING LEADER | 44 | GEAR WASHER | | |