



AFTER DARK BR 5000/8000/10000

PART NO.	PART NAME	PART NO.	PART NAME	PART NO.	PART NAME	PART NO.	PART NAME
1	DRAG BUTTON ASSEMBLY	27	BEARING COVER	53	SCREW	79	CLICK RATCHET
2	SPOOL ASSEMBLY	28	OWC COVER (##)	54	SCREW	80	DRAG STEM
3	MAIN SHAFT WASHER	29	BALL BEARING	55	CRANK ASSEMBLY	81	WASHER
4	CLICK RATCHET	30	BEARING HOLDER (##)	56	SCREW	82	EARED DRAG WASHER
5	MAIN SHAFT ASSEMBLY	31	SPACER	57	LEFT BAIT LEVER	83	KEYED DRAG WASHER
6	PICK UP HOUSING NUT	32	WASHER	58	BAIT CAM	84	DRAG SPRING
7	SCREW	33	O.W.C ASSEMBLY	59	BAIT LEVER SPRING	85	WASHER
8	LOCK WASHER	34	SPACER	60	CLICK SPRING	86	DRAG SLEEVE
9	SCREW	35	PINION	61	SCREW	87	REAR COVER
10	BAIL WIRE ASSEMBLY	36	SCREW	62	SCREW	88	SCREW
11	LINE ROLLER SLEEVE	37	N-R PAWL	63	LEVEL WIND HOLDER	89	DRAG KNOB SCREW
12	NON-TWIST LINE ROLLER	38	N-R SPRING	64	LEVER WIND BRACKET	90	DRAG INSERT COVER
13	WASHER	39	NR STEM SPRING	65	SCREW (##)	91	DRAG SCREW HEAD CAP
14	LINE ROLLER WASHER	40	N-R STEM	66	LEVEL WIND GEAR COVER (##)	92	SPRING PIN
15	BAIL BRACKET	41	N-R SCREW	67	LEVEL WIND GEAR	93	DRAG KNOB
16	SCREW	42	O RING	68	BALL BEARING (#) / BUSHING (##)	94	CLICK PISTON
17	SCREW	43	N-R LEVER	69	BAIL PAWL SUPPORTER	95	CLICK PISTON SPRING
18	TRIP PISTON	44	SCREW	70	RIGHT BAIT LEVER	96	O RING
19	TRIP SPRING	45	FRAME	71	SCREW	97	WIRE SPRING
20	TRIP SPRING HOLDER	46	HANDLE LOCK SCREW	72	SCREW	98	DRAG KNOB RING
21	BAIL TRIP WIRE	47	HANDLE WASHER	73	BAIT SLIDER	99	DRAG KNOB COVER
22	SCREW	48	BALL BEARING	74	SCREW	100	SCREW
23	BAIL ARM COVER	49	DRIVE GEAR ASSEMBLY	75	BAIT PAWL COVER	101	RETAINING STRING
24	PICK UP HOUSING	50	WASHER	76	BAIT PAWL	102	KEYED WASHER
25	SPACER	51	BALL BEARING	77	BAIT PAWL SPRING	103	DRAG WASHER
26	SCREW	52	COVER PLATE	78	WASHER	104	EARED DRAG WASHER
		(#)	AD 5000 BR ONLY	(##)	AD 8000 / 10000 BR ONLY		

AFTER DARK BR 5000/8000/10000