



## BROWNING XCITE BF

KEY NO.	PART NAME
1	DRAG BUTTON ASS'Y
2	SPOOL ASS'Y
3	MAIN SHAFT WASHER
4	CLICK RATCHET
5	MAIN SHAFT
6	PICK UP HOUSING NUT
7	SCREW
8	LOCK WASHER
9	SCREW
10	BAIL WIRE ASS'Y
11	WASHER
12	LINE ROLLER BUSHING
13	LINE ROLLER
14	WASHER
15	LINE ROLLER WASHER
16	BAIL BRACKET
17	SCREW
18	TRIP PISTON
19	TRIP SPRING
20	TRIP SPRING HOLDER
21	BAIL TRIP WIRE
22	SCREW
23	BAIL ARM COVER
24	PICK UP HOUSING
25	WASHER
26	SPACER
27	SPACER
28	WASHER
29	OWC ASS'Y
30	SPACER
31	SCREW
32	BEARING COVER
33	BALL BEARING

KEY NO.	PART NAME
34	PINION
35	SCREW
36	N-R PAWL
37	N-R SPRING
38	NR STEM SPRING
39	N-R STEM
40	N-R SCREW
41	N-R LEVER
42	SCREW
43	FRAME
44	HANDLE LOCK SCREW
45	HANDLE WASHER
46	BALL BEARING
47	DRIVE GEAR ASS'Y
48	WASHER
49	BALL BEARING
50	COVER PLATE
51	SCREW
52	SCREW
53	CRANK ASS'Y
54	SCREW
55	LEFT BAIT LEVER
56	BAIT CAM
57	BAIT LEVER SPRING
58	CLICK SPRING
59	SCREW
60	SCREW
61	LEVEL WIND HOLDER
62	LEVER WIND BRACKET
63	LEVEL WIND GEAR
64	BALL BEARING
65	BAIL PAWL SUPPORTER
66	BAIT SLIDER

KEY NO.	PART NAME
67	SCREW
68	BAIT PAWL COVER
69	BAIT PAWL
70	BAIT PAWL SPRING
71	RIGHT BAIT LEVER
72	SCREW
73	SCREW
74	WASHER
75	CLICK RATCHET
76	DRAG STEM
77	WASHER
78	EARED DRAG WASHER
79	KEYED DRAG WASHER
80	DRAG SPRING
81	WASHER
82	DRAG SLEEVE
83	REAR COVER
84	SCREW
85	DRAG KNOB SCREW
86	DRAG INSERT COVER
87	DRAG SCREW HEAD CAP
88	SPRING PIN
89	DRAG KNOB
90	CLICK PISTON
91	CLICK PISTON SPRING
92	O RING
93	WIRE SPRING
94	DRAG KNOB RING
95	SCREW
96	DRAG KNOB COVER
97	RETAINING STRING
98	KEYED DRAG WASHER
99	DRAG WASHER
100	EARED DRAG WASHER