



## ZEBCO CURSUS RUNNER 3000/4000

- |     |                                 |     |                                  |
|-----|---------------------------------|-----|----------------------------------|
| 1   | Housing                         | 45  | Click Ratchet                    |
| 1A  | R.S.Rear Cap                    | 46  | Thrust Washer                    |
| 2   | Housing Ball Bearing(2 req.)    | 47  | Bearing Cover                    |
| 3   | Main Gear Assembly              | 49  | Rear Drag Ratchet                |
| 3A  | Main Gear Shim                  | 50  | Rear Ratchet Insert              |
| 4   | Crosswind Gear                  | 51  | U Model Washer                   |
| 5   | Crosswind Gear Ball Bearing     | 52  | Rear Keyed Washer                |
| 6   | Crosswind Gear Screw            | 53  | Rear Drag Washer                 |
| 7   | Crosswind Block                 | 54  | Rear Eared Washer                |
| 8   | Spool Shaft Clip                | 55  | Rear Drag Spring                 |
| 9   | Crosswind Block Screw           | 56  | Rear Drag Nut                    |
| 11  | Liveliner plate                 | 58  | Rear Drag Knob                   |
| 12  | Liveliner Dog                   | 59  | Rear Drag Knob Retainer          |
| 13  | Screw                           | 60  | Rear Drag Knob Grip              |
| 14  | Dog Spring                      | 67  | Handle Assembly                  |
| 15  | Liveliner Liveliner Eccentric   | 73  | Rotor Cup                        |
| 16  | Liveliner Eccentric             | 75  | Cover Screw                      |
| 17  | R. S. Liveliner Eccentric Lever | 76  | Balance Weigh                    |
| 18  | Liveliner Eccentric Lever Screw | 77  | Trip Lever                       |
| 20  | Eccentric Trip                  | 78B | Bail Arm Spring                  |
| 21  | Trip Spring                     | 80  | Bail Pivot Cover                 |
| 23  | Trip Screw                      | 81  | Bail Arm                         |
| 24  | Housing Cover                   | 82  | Bail Arm Screw                   |
| 24A | L.S.Rear Cap                    | 83  | Bail Stud Screw                  |
| 25  | Rear Drag Click                 | 86  | Line Roller Ball Bearing(2 req.) |
| 26  | Housing Cover Screws(4 req.)    | 87  | Line Roller                      |
| 27  | (Mid)Liveliner Eccentric Lever  | 88  | Line Roller Shaft                |
| 28  | L.S.Liveliner Eccentric Leve    | 89  | Bail Wire                        |
| 29  | Liveliner Eccentric Lever Screw | 90  | Bail Side                        |
| 31D | Spring                          | 90B | Balance Weight(2 req.)           |
| 33  | Eccentric Lever                 | 91  | Rotor Nut                        |
| 34  | Eccentric                       | 93  | Spool Assembly                   |
| 35  | Eccentric Spring                | 94  | Line Hook                        |
| 36  | Eccentric Lever Mounting Screw  | 99  | Spool Assembly Click             |
| 37  | Pinion Gear                     | 100 | Friction Drag Washer(3req.)      |
| 38  | Pinion Ball Bearing(2 req.)     | 101 | Keyed Washer(2 req.)             |
| 40  | Bearing Mounting Screws(3 req.) | 102 | Drag Washer Eared                |
| 40D | Clutch Retainer                 | 103 | Retaining Ring                   |
| 43D | Collar                          | 110 | Drag Knob                        |
| 43  | Rotor Cup Washer                |     |                                  |
| 44  | Spool Shaft                     |     |                                  |

ZEBCO CURSUS RUNNER 3000/4000