



RHINO WIZARD LCLD 420

Key No.	Description	Key No.	Description
1	SCREW	41	SPRING
2	CLICK KNOB	42	ANTI REVERSE PAWL
3	PLAM SIDE COVER	43	GEAR SIDE COVER
4	WASHER	44	QUADRANT RING
5	CLICK PATCH	45	LOCATING COLLAR
6	E-CLIP	46	SCREW
7	GEAR	47	WASHER
8	SPRING CLIP	48	WASHER
9	LINE COUNTER ASSY	49	DRAG LEVER
10	BALL BEARING	50	BRAKE ECCENTRIC
11	WINDOW	51	O RING
12	3M TAPE	52	WASHER
13	SCREW	53	SPRING
14	FRAME ASSY	54	DRAG KNOB ASSY
15	SCREW	55	BUSHING
16	TRANSMISSION GEAR	56	CLICK PIN
17	E-CLIP	57	CLICK SPRING
18	MAIN SHAFT	58	BUSHING
19	WASHER	59	GEAR SIDE COVER COSMETIC RING
20	DISH WASHER	60	WASHER
21	BUSHING	61	KEY WASHER
22	BALL BEARING	62	HANDLE ARM SPACER
23	SPOOL	63	HANDLE ASSY
24	DRAG WASHER	64	HANDLE NUT
25	BALL BEARING	65	SCREW
26	SPRING	66	IDLER GEAR
27	DRAG PLATE	67	LINE GUIDE GEAR
28	SPOOL CARRIER	68	SCREW
29	GEAR SHAFT	69	LOCK PLATE
30	SCREW	70	WORM SHAFT-1
31	SCREW	71	COLLAR
32	GEAR COVER	72	LINE GUIDE SHAFT
33	SCREW	73	WORM SAHTE-2
34	MAIN GEAR	74	BALL BEARING
35	BUSHING	75	SCREW
36	RATCHET	76	LINE GUIDE CARRIER
37	WASHER	77	LINE GUIDE RETAINER
38	MAIN GEAR SHAFT	78	LINE GUIDE PAWL
39	E-CLIP	79	WASHER
40	WASHER	80	LINE GUIDE RTAINER NUT